

Getting started with CAL-EDGE-0 device

Thank you for purchasing CALMS device. Further in this document you will find how to start using it.

CONNECTING ANTENNA & POWER SUPPLY

1. Connect the **antenna** to CAL-EDGE-0. Install antenna connector to »**ANT1**« port and screw it firmly. Place antenna where signal reception is best (near the window, higher place,...).
2. Connect the device to **power supply**. »**STATUS**« led starts blinking when the device successfully connects to the internet. It can take up to 10 minutes, depends on mobile signal strength.



Terminal	Meaning										
LAN	<ul style="list-style-type: none"> - Used to connect device to any other TCP/IP protocol capable device (MODBUS TCP, ADS...). - Can be used to connect device on internet (DHCP server must be installed in the network!) 										
LED RS485	<ul style="list-style-type: none"> - If MODBUS communication between sensor and device is established, LED flashes rapidly (red color). - If LED is not flashing communication is not established. 										
LED STATUS	<table border="1"> <thead> <tr> <th>LED Status</th> <th>Module Status</th> </tr> </thead> <tbody> <tr> <td>On</td> <td>Searching Network/Call Connect</td> </tr> <tr> <td>200ms On, 200ms Off</td> <td>Data Transmit</td> </tr> <tr> <td>800ms On, 800ms Off</td> <td>Registered network</td> </tr> <tr> <td>Off</td> <td>Power off / Sleep</td> </tr> </tbody> </table>	LED Status	Module Status	On	Searching Network/Call Connect	200ms On, 200ms Off	Data Transmit	800ms On, 800ms Off	Registered network	Off	Power off / Sleep
LED Status	Module Status										
On	Searching Network/Call Connect										
200ms On, 200ms Off	Data Transmit										
800ms On, 800ms Off	Registered network										
Off	Power off / Sleep										
CAN – BUS / RS485	<ul style="list-style-type: none"> - Terminal used to connect RS485 fieldbus. - To properly connect the sensor check the electric scheme! 										
DC IN	<ul style="list-style-type: none"> - Power supply terminal. - Device accepts voltage 9-24VDC. 										
ANT1, ANT2	<ul style="list-style-type: none"> - Used for antenna connection with SMA connector. - ANT1 is MAIN terminal! Connect antenna to ANT1 terminal! - Mount antenna on the place with best signal reception possible! 										
ANT3, ANT4, ANT5, PROG, SERIAL	<ul style="list-style-type: none"> - Not used 										


START USING CALMS APPLICATION

1. Device will start capturing data after it is configured on CALMS → Open CALMS app.calms.com
2. Create new »System«, add device into the system and connect sensors to it. (<https://docs.calms.com/getting-started/web/setting-up-your-system/>)

CONNECTING SENSORS

MODBUS RTU SENSORS

1. Device has one RS485 port where MODBUS RTU sensors are connected. (check the picture below)
2. Connect sensors accordingly to configuration you've done on CALMS system setup. **Double check the communication parameters and sensor MODBUS addresses!**
3. Follow the installation guide provided on CALMS (https://docs.calms.com/resources/field_installation_setup_guide_template/)
4. »RS485« LED is blinking red if the device communicates with connected sensors.
5. Check sensor values on the »**Device dashboard**« page.



MODBUS TCP SENSORS

1. Device has one ethernet port (»LAN«) where MODBUS TCP sensors are connected.
2. Device receives its static IP address (**192.168.0.102**) after start-up if there is not DHCP server in the network.
3. Connect sensors accordingly to configuration you've done on CALMS system setup. **Double check the sensors IP addresses!**
4. Follow the guide provided on CALMS
(https://docs.calms.com/resources/field_installation_setup_guide_template/)
5. Check sensor values on the »**Device dashboard**« page.

TROUBLESHOOTING

- **»STATUS« LED is constantly off:**
 - check the power supply. Device accepts 9-24VDC.
- **Device does not want to connect to the internet:**
 - Connect the antenna firmly on »ANT1« port.
 - Place the antenna near windows and on higher places.
 - Reboot the device,
- **MODBUS communication is not working:**
 - Follow the installation guide provided on CALMS
(https://docs.calms.com/resources/field_installation_setup_guide_template/)
 - Check the configuration on CALMS (communication parameters)

For more instructions and troubleshooting scan the QR code!



If you have any difficulty, please contact support team for further assistance.

Contact: support@calms.com

When contacting support team, please send them the serial number of your device (written on back of device).